



# TONE FINISH TONER VAN DYKE BROWN #SN129

## TECHNICAL DATA SHEET

PRODUCT NUMBER	DESCRIPTION
M101-0290	TONE FINISH TONER VAN DYKE BROWN #SN129

### PRODUCT DESCRIPTION:

Mohawk Tone Finish® Toners are used throughout the industry for quick efficient professional touch-up. Tone Finish® Toners contain finely ground, non-fading pigments for color repairs that last. Toners adapt to various methods so as to blend in spot repairs. Adjustment of sheen is achieved with a topcoat of clear lacquers available in gloss, satin, flat and dead flat.

### ADVANTAGES:

1. Hap's compliant.
2. Aerosol form, no extra equipment needed.
3. Feathers in invisibly for touch-up repairs.
4. Available in a wide variety of wood finishing shades.

### PHYSICAL PROPERTIES AND SPECIFICATIONS

Technology	Nitrocellulose lacquer toner
Color	Semi-transparent grey
Sheen	Gloss
Viscosity	N/A
WPG	6.436734337 lbs/gal
Solids by Volume	5.833521468 ±1%
Solids by Weight	9.553392204 ±1%
Flash Point	-76.000000000 °F
HMIS	H: 2, F: 4, R: 0, P: X
Coating VOC (g/l)	682.186271387 g/l
Coating VOC (Lb/Gal)	5.693140649 lbs/gal
Material VOC (g/l)	592.430500660 g/l
Material VOC (Lb/Gal)	4.944089769 lbs/gal
#VOC/#Solid	8.040131560 lbs/lbs solid
VHAP Ratio (#VHAP/#Solid)	0.578266120
Spread Rate	93.569684347 sq. ft./gal @ 1.0 mil DFT (no loss)
Catalyst/Ratio	N/A
Reducer	N/A
Retarder	N/A
AirDry	To touch: 7 minutes; To handle: 15 minutes; To package: overnight
Oven Dry	N/A
Shelf-Life (Unopened)	36 months
Pot-Life (Catalyzed)	N/A
Recoat Instruction	As needed for color. Allow to dry to a tack between coats.
PH	N/A

**DIRECTIONS:**

Clean surface to be sprayed with Mohawk Wax Wash™ Remover. For best results, can temperature should be 65 – 90 deg. F. SHAKE WELL BEFORE USING for at least one minute after ball rattles to ensure color uniformity. Point opening of spray button toward object, holding can 12 – 14 inches away from surface to be coated. Press spray button firmly. Use steady, even strokes. Several thin coats give a better finish than one heavy coat. Allow coating to become tacky between coats. Clean spray button immediately by spraying with can upside down until no more product comes out. If clogged, remove spray button with a twisting motion and clean. Gently twist button onto can with opening turned away from you.

*The data on this sheet are calculated values (as formulated) and will not represent exact values for every product. For Safety and Other Precautions, read the SDS before using the product. SDS are available upon request. If Safety Data Sheet is required, contact: Mohawk Finishing Products, a Division of RPM Wood Finishes Group, Inc.; P.O. Box 22000 Hickory, NC 28603; Phone: 1-800-545-0047; Fax: 1-800-721-1545.*

*Drying times and viscosities reported are as tested under laboratory conditions (77°F (25°C)) with relative humidity of approximately 45%. Changes in temperature and humidity will affect product data.*

*It is the user's responsibility to verify product compliance with all applicable regulations or permits before proceeding with use. Always pretest any finishing products to verify suitability to the desired use before proceeding with any application. Manufacturer makes no warranties, express or implied, including (but not limited to) warranties of merchantability and fitness for particular purposes. Manufacturer will not be liable for any incidental, consequential or special damages or losses derived, directly or indirectly, from or as a consequence of purchaser's use of this product.*

TDS. Mohawk Finishing Products, Division of RPM Wood Finishes Group, Inc. All rights reserved.